

Performance Analysis of a Two Stage Axial Fan

AE 451A - Experiments in Aerospace Engineering-III

Propulsion Laboratory
Department Of Aerospace Engineering
Indian Institute of Technology - Kanpur

Objectives

1. To obtain and understand the characteristics of an axial fan.
2. To plot and understand the pressure profiles at different points across an axial fan.

Description




Figure 1. Two Stage Axial Fan Test Facility.

The axial flow fan test facility consists of two stage axial fan, along with a switch cabinet that will display all relevant operating data, see Figure 1. Each axial rotor has its own motor and speed of each motor can be regulated independently from the switch cabinet using potentiometers. Experiments can be conducted with single rotor also. A movable pipe section component is located directly after the intake pipe in the experimental setup which contains rotor 1. If experiments are to

be carried out with only one stage, the movable pipe section can be pushed to the side so that the intake pipe can be screwed directly onto the pipe section containing rotor 2.

A throttle valve is fitted in the pipe section with rotor 2. It can be used to regulate the mass flow and discharge pressure through the compressor. The throttle valve is operated using a lever, which is secured with a wing bolt to prevent unintentional adjustment. See Figure 1 for more details. Pressure measuring connections are fitted at the key points for pressure measurements in the intake pipe, which the user can connect to differential pressure displays in the system (see Figure 2). The holes feed into annular pipes, which are designed to rule out falsification of the measured pressures. The flow rate through the pipe is measured using the static pressure measurement at the inlet. Finally, there are sensors for measuring the air temperature at various locations.




Figure 2. Location map of the apparatus

The switch cabinet for the system is divided into two sections. Left-hand section contains digital displays for differential pressures, temperatures, air flow rate, nulling yaw probe (position and angle). It also contains the connection for PC data acquisition. The sensor connections are located on the side of the control cabinet. Right hand side of the cabinet contains emergency stop switch and an ON/OFF button for the fan. The torque and speed of the fan are also shown on the digital display. On the right hand side of the cabinet are two sockets, which can be used to connect additional devices (e.g. a PC).

Experimental Procedure

To obtain the compressor characteristics of an axial compressor

1. Set the throttle valve to minimum resistance position, by rotating the lever.
2. Rotate the RPM control switch of both the rotors till the desired RPM is reached.
3. Torques and pressures are measured using various sensors and the readings are displayed in the displays located in the switch cabinet. This corresponds to the first set of readings, note down these readings.
4. Slowly rotate the lever to certain extent to increase the flow resistance (and reduce the mass flow rate), keeping the RPM constant.
5. Note down the torque and pressure readings for this setting as well. Keep repeating this process so that you get 5-8 readings.
6. Then repeat the same experiment at different RPM (at least three different RPMs). The RPMs for each group will be defined by the instructor.

Following readings should be noted:

- 1) Pressure at various points (P1 – P7).
- 2) Air flow rate (m^3/s) and RPM from the switch cabinet.
- 3) Temperatures at various points (T1 – T3).
- 4) Torque in N-m from the switch cabinet.




Figure 3. Typical characteristic map of a transonic fan for a civil aircraft jet engine.

[ref: Dixon S. L., Hall C. A., *Fluid Mechanics and Thermodynamics of Turbomachinery*, 7th Edition, 2014]

Calculations

1. Calculate the static pressure (P_0) at the inlet. Use Bernoulli equation between the stagnant ambient air and the air at the inlet section. Obtain velocity of air (average value) at the inlet section from the air volume flow rate and the inlet area. Inlet duct diameter is 40 cm.

Results

1. Plot overall pressure ratio (P_7/P_0) vs. mass flow rate (\dot{m}) for the three different RPM (N) settings. Here we are considering that the total pressure is equal to the static pressure because the flow Mach number is low in the present case. Note that the gage pressure must be converted to absolute pressure wherever applicable.
2. For a particular RPM and throttle setting in the stable region, plot the pressure profiles across different points (P_0 to P_7).
3. For a particular RPM setting, plot the ratio $(Q \times \Delta P) / (\text{power input})$ w.r.t. the volume flow rate (Q , m^3/s). Calculate the power input (in W) from torque and RPM. Use $\Delta P = P_7 - P_0$, in Pa.

Discussion

1. Briefly discuss the nature of the obtained plots.

Precautions

1. Prior to measurement, all the pressure sensors must be set to “0”. To do this, press the RST button on the display (only for pressure not for temperature).
2. Vary RPM in a controlled manner. Never exceed 2100 RPM (75% of the rated RPM, i.e. 2800 RPM).
3. In case of an emergency, stop the setup by pressing emergency stop switch located on the right side of the switch cabinet.
4. Ensure that all wires are properly insulated. If there is any open length of wire, wrap insulation tape around it or replace the wire.
5. If both fans are to be operated at the same time, they must be switched ON at the same time. Once one fan is already being operated at a higher speed, second fan cannot subsequently be switched ON.
6. Do not take measurements continuously. Give a minimum time gap of 60 seconds between measurements after changing the throttle valve position or RPM.